


# ST IMAGING REMOTE FILM ACCESS SYSTEM

## How it works...

### STEP 1

Request access to a roll of film from the **Host Library's Film Archive** that may be hundreds or thousands of miles away.



### STEP 2

Mount the roll of film on the **ST200 Remote Film Access System** at the Host Library and authorize remote access.



ST200 RFA Digital Film Viewer & PC at Host Library

Image Transmission & Network Components

### STEP 3

Access Host System from any **Remote Location**.



View, Scan, Store, Print Digital Images



Remote Film Access User



**S-T IMAGING, INC.**

*division of Digital Check Corp.*

Tel: 847 / 501-3344 • Fax: 847 / 501-3377 • [www.stimaging.com](http://www.stimaging.com) • email: [info@stimaging.com](mailto:info@stimaging.com)

466 Central Ave., Suite 31 • Northfield, IL 60093 USA