

EYECOM 10,000 CANON MP60

**READER/
PRINTERS**

**FOR
MOTORIZED
COMBO
CARRIER**



**MOUNTING
INSTRUCTIONS
& USER'S MANUAL**



S-T IMAGING, INC.

**466 Central Avenue, Suite 31
Northfield, Il 60093**

Phone: (847) 501-3344 • Fax: (847) 501-3377

web site: www.stimaging.com



e-mail: info@stimaging.com

a subsidiary of Digital Check Corp.

CARRIER MOUNTING INSTRUCTIONS



Step 1

- A. Turn OFF the reader/printer and remove the lens holder and fiche carrier.



USER'S MANUAL – Speed Control Functions

SPEED CONTROL PAD



Step 3




TO THREAD FILM: Pull handle to open top glass, then load film on the left spindle.

Step 4




Feed film from over the top of the reel, under first white guide roller, between glass flats, under second guide roller and into the take-up reel slot.


Step 2



A. Fit the two guide posts on the bottom of the carrier into the groove on the carrier stage.



Hook, Groove, and Guide Post



C. Set the HOOK at the rear of the carrier to the rear of the carrier stage. Fit the two guide posts on the bottom of the carrier into the groove on the carrier stage.

Step 3



A. Center the Combo Carrier on the hook at the rear of the carrier stage (see photos on previous page).



B. Completed Mounting.



C. Plug the Combo Carrier into the Power Jack.

Step 1

Adjustable Film Guides

PULL OUT for 35mm Setting as shown.



Step 2

Adjustable Film Guides

PUSH IN for 16mm Setting as shown.

